

Setting up the Kombo Loom

At the back of the loom there is a nylon tube embedded in the loom, on the left hand side. Make sure it is out.



The nylon tube

Nylon tube out.



Imagine a frame with a purse handle. Each harness should have a cord attached to it like a purse handle. The handle also runs through those U shaped metal guide on the back of the loom. So, take one end of the cord and attach it to the plastic tab through the hole at the top. (Like in the picture below) Thread the open end through the U shaped metal guide. Then thread it through the one on the other side of the loom. Then attach that end to the plastic tab which closes off the system.



Plastic harness ends. Cord is attached through the hole.



Cord goes through U shaped metal guide.



Complete Harness with attached cord

Now make a loop with the harness cord and stick it through the hole going from the back to the front.



Stick the harness cord through the hole



This is the cord coming through the front



Thread this through hole on the toggle



Then bring the loop over the top of the toggle and pull it tight.



Ta da!

Start with Harness 1 first and work towards the back of the loom. When you want to insert the harness into the grooves, put the right side in to the groove first and then you will see on left side of the loom (This is while standing at the back) that the plastic side of the harness will slide in and then down. After you have put on all your harnesses you need to put the nylon tube back in the horizontal groove. This will keep the harnesses from falling out when the loom is folded down.



Inserting the harnesses into the grooves